

# Tow Behind Roaster

Open main cylinder valve.



1. The E-Z Way Roaster is equipped with a manual control valve attached to a thermocouple
  
2. To light the E-Z Way Roaster:
  1. Turn Control to Pilot Position.
  2. Depress dial - hold for one (1) minute
  3. Press electronic ignitor, holding dial down, until pilot lights.
  4. Keep dial depressed for 1 minute - release and turn dial counterclockwise to full ON position.
  5. Turn control to adjust the flame.
  6. If pilot fails to ignite, retry steps 2 & 3.
  7. After burner ignites, allow the roaster 10 to 15 minutes to heat up to your selected cooking temperature.
  8. If using the E-Z Way to reheat foods or as a griddle, plug the grease drain and remove the grill rack. Place food directly on the inside stainless steel pan. If roasting or smoking meat, use the grill rack provided. We suggest roasting and smoking at 225° to 275° F. A meat thermometer should be used to insure the finished product is thoroughly cooked.
  9. Authentic, smoked barbecue flavor is obtained by using the wood smoke trough. The most effective way to use the smoker trough is to use wood chips that have been soaked in water for at least 24 hours prior to use.
  
3. To turn off:
  1. Rotate knob clockwise to pilot position.

Press down and turn to OFF position.