

HOTDOG ROLLER



INSTRUCTIONS

1. PLUG DIRECTLY INTO GROUNDED THREE PRONG OUTLET.
2. DO NOT USE WITH ADAPTERS OR EXTENSION CORDS.
3. REQUIRE A WARM UP TIME OF AT LEAST 15 MINUTES.

