

Rotisseries



1. These Big John Products are designed **FOR OUTDOOR USE ONLY!**
2. For safety sake, keep the motor unplugged until the rotisserie is completely setup, loaded and balanced. We recommend that the spit be loaded prior to igniting the charcoal.
3. Place one support bar clamp on the spit, and slide the clamp all the way to the end of the bar, followed by one skewer with prongs facing inward. Insert pointed end of the spit through the center of the length of meat. Before proceeding, make sure the meat is balanced on the spit.
4. When meat is balanced, install the second skewer and support bar clamp. If cooking a large roast, use support bar as needed to secure the load. Make sure that the meat and the support bar are centered between the rotisserie height adjustment posts and the posts are the same height.
5. Tighten the thumb screws of all the stainless steel hardware. As the meat cooks, shrinkage may occur and the skewers may need to be adjusted to hold the meat firmly.
6. Remove the entire spit assembly and ignite the charcoal as outlined previously. When coals are ready and placed properly, place hot coal covers over the charcoal.
7. Remove the chain guard by loosening the wing nut. Place the rotisserie spit with the meat centered, in the point protector and motor end mounts. Where the spit makes contact with these mounts, lubricate with WD-40.
8. Loosen the aluminum knob (locking washer must be in place) on the adjustable motor mount so the chain slips over both drive sprockets. Adjust the slide action so that the chain is taut. Retighten the aluminum knob. Before operating the rotisserie, the chain guard must be properly installed.

9. WARNING: BIG JOHN ROTISSERIES SHOULD NOT BE OPERATED WITHOUT THE CHAIN GUARD IN PLACE.

10. Plug into approved outdoor electrical outlet, turn the motor on and remove the hot coal covers and begin cooking. We recommend adding 10 lbs. of charcoal every hour while the rotisserie is in use.

When meat is cooked, place hot coal covers over the charcoal and carve meat directly from the spit, or remove spit from unit and move over to a carving table.