

White Patio Heater



START

1. To light the pilot, the first step is to purge the gas line leading to the pilot assembly. Press and turn the control knob to "HIGH" position and keep it depressed in for 1 to 2 minutes. NOTE: When a new or refilled gas cylinder is installed, the heater will need to be purged again.

2. To light the pilot:

- a) Press the control knob and turn to the "PILOT" position.
- b) Hold the control knob in and press the ignition button until the pilot lights.
- c) Keep the control knob depressed for 30 seconds to heat the thermocouple.
- d) Release the control knob and the pilot should stay lit. Note: To visually check the ignition of the pilot, slide the viewing hole cover to either side.
- e) Once the pilot flame stays on, close the viewing hole cover.

CAUTION: Do not attempt to slide the viewing hole cover when the main burner is lighting, operating or hot.

3. Set the heat level.

- a) Press and turn the control knob to "HIGH" position, the burner will light immediately.
- b) Press and turn the control knob to the desired heat level. Note: While in use, the burner flame should be mainly blue in appearance with a small amount of yellow.

STOP

1. Press and turn the control knob to "PILOT" position, the burner will extinguish but the pilot will stay on.
2. To extinguish the pilot, press and turn the control knob to "OFF" position.
3. Turn off gas supply.
4. Do not attempt to relight the heater for 5 minutes after the LP cylinder valve has been closed.

RESTART AFTER SAFETY SHUTDOWN

1. Turn the gas control knob to "OFF" position.
2. Wait 5 minutes.
3. Restart following "Start" procedure.